

CPS Auto cable cam controller



FEATURES

Four selectable operation mode

Normal mode: Maneuver between two fix vital points to prevent cable cam collision(DF and DS points)

Point to point mode: Maneuver between two editable points(A and B points)

Swing mode : continues movement between editable points(A and B points)

Movement record mode for record and play camera and dolly movements

Failsafe mode and back to home in radio control signal lost

Battery power monitor (first visual LED alarm in weak voltage level then Back to home in vital voltage level)

Adjustable movement speed

High power RGB LED indicator to show different situations and working modes

Self test and failure diagnose

Adaptable to any type of cable cam

Adaptable to any type of commercial radio controls on the market (SBUS,DBUS,SUMD,PPM,PWM Protocols)

Precise encoder base positioning

